9.4 JOG DIAL SECTION



JOG DIAL SECTION PARTS LIST

Mark	No.	Description	Part No.
	1	INDB Assy	DWX2986
	2	JFLB Assy	DWX2984
	3	JOGB Assy	DWX2985
	4	JOG Panel	DAH2609
	5	JOG Plate	DAH2679
	6	Load Spring	DBH1680
	7	SW Spring	DBH1681
	8	SW Cushion HH48/2	DEC2538
	9	Ring Cushion L24/2.0	DEC2958
	10	Washer	DEC3137
	11	Link Plate	DNH2848
	12	JOG B	DNK4068
	13	SW Ring	DNK5233
	14	Load Gear	DNK5236
	15	Smoother	DNK5237
	16	JOG Holder	DNK5240
	17	Comp Plate	DNK5243
	18	Adjust Plate	DNK5300
	19	Cam Plate	DNK5301
	20	Dial Gear	DNK5302
	21	Link Gear A	DNK5303
	22	Link Gear B	DNK5304
	23	Rack Plate	DNK5305
	24	Sheet SW	DSX1078
	25	JOG Dial A Assy	DXA2159
	26	•••••	
	27	•••••	
	28	Roller A Assy	DXB2010
	29	JOG Stay Assy	DXB2015
	30	•••••	
	31	•••••	
	32	•••••	
	33	Encoder Spring	DBH1710
	34	Encoder Plate	DEC2889
	35	Gear A	DNK5241
	36	Gear B	DNK5242
	37	•••••	
	38	•••••	
	39	Screw (FE)	DBA1265
	40	•••••	
	41	Screw	BPZ20P100FTC
	42	Screw	BPZ30P080FNI
	43	Screw	IPZ20P060FTC